



ACCESS CODE	QUANTITIES	ACCESSORY
A	8 Pcs	
C	12 Pcs	
M	32 Pcs	30*8MM
N	36 Pcs	40*5MM
	1 Pcs	
X	12 Pcs	black cotton pad diameter 28MM
Y	2 Pcs	Height 22CM
Z	4 Pcs	X2 X2 Leg Installed

STEPS		PLEASE REFER TO THE PICTURES FOR SPECIAL OPERATIONS
①		Install Type C angle irons on the headboard, side rails and footrest, and then paste Type X.
②		Use Type A straight irons to connect the headboard and side rails.
③		Use Type A angle irons to connect the side rails and foot rest.
④		Install the stand Y to the folding slat. The stand Y can be adjusted according to the slat.

Note: the 32 pcs Type M bolts are not in the hardware kit. They are already pre-installed in the holes of the frame.

