ASSEMBLY INSTRUCTIONS | ICON HIGH CHEST









PARTS CHECKLIST

Wooden Dowels (8 pcs)

Screws for Feet (4 pcs)



Turn the dresser over on its back and attach the feet. Remove the drawers in order to complete this step.

