

ASSEMBLY INSTRUCTIONS | LOOM BARSTOOL

HARDWARE CHECKLIST		
A		JCBC Bolts M6x60mm (4pcs)
B		Flat Washers M6xØ18mm (4pcs)
C		Spring Washers M6xØ11mm (4pcs)
D		Allen Key (1pc)

Step 1

