



ASSEMBLY INSTRUCTIONS | LOOM OUTDOOR BARSTOOL

HARDWARE CHECKLIST		
A		JCBC Bolts M6x60mm SS (4pcs)
B		Flat Washers M6xØ18mm SS (4pcs)
C		Spring Washers M6xØ11mm SS (4pcs)
D		Allen Key (1pc)

Step 1

