

ASSEMBLY INSTRUCTIONS | LOOM OUTDOOR ARM CHAIR

PARTS CHECKLIST		
A		JCBC Bolts M6x60mm (4 pcs)
B		Flat Washers M6x18mm (4 pcs)
C		Spring Washers M6x11mm (4 pcs)
D		Allen Key (1 pc)

Step 1

