










ASSEMBLY INSTRUCTIONS | DEXTER DINING CHAIR


PARTS CHECKLIST	
A	Back Frame (1pc)
B	Seat Frame (1 pc)
C	Front Leg (2pcs)
D	Left Rail (1pc)
E	Right Rail (1pc)

HARDWARE CHECKLIST		
F		Short Bolt (6pcs)
G		Long Bolt (4pcs)
H		Spring Washer (10pcs)
I		Flat Washer (10pcs)
J		Screw (4pcs)
K		Dowel (2pcs)
M		Allen Key (1pc)
N		Screwdriver (Not Included)




Please do not discard any packaging until you have checked that all the parts and hardware are present.

Step 1




Step 2




ASSEMBLY INSTRUCTIONS | DEXTER DINING CHAIR


Step 3




Step 4



Step 5




Step 6




ASSEMBLY INSTRUCTIONS | DEXTER DINING CHAIR


Step 7




Step 8



Step 9




Step 10



ASSEMBLY INSTRUCTIONS | DEXTER DINING CHAIR

Step 11



Finish

